



Yellow Products

630-293-8013

Toll Free 877-"SAVE"TY-1

Fax 630-876-1993

Hand Rail Installation Instructions (Modular)

Galvanized cast iron fittings



1. Position base fittings (#SYP-12) as needed along the hand rail run.
2. Drop in posts and 'hand' tighten the set screws on the bases with an allen wrench (Figure 1).
3. Get the next rail which will be used as the mid-rail.
4. To each end of the mid-rail attach the fitting appropriate to the rail's position on the hand rail run.
End - #SYP-03 (Figure 3)
Inline - #SYP-22 (Figure 4)
Corner - #SYP-21
5. Once the correct fittings have been attached, slide down the fittings attached to the mid-rail over the first two existing posts, and stop at the 21" inch mark and tighten down the set screws on the mid-rail fittings.
6. Use a level to ensure the mid-rail is level (Figure 2).
7. Get the next rail which will be used as the top-rail.
8. To each end of the top-rail attach the fitting appropriate to the rail's position on the hand rail run.
End - #SYP-02 (Figure 5)
Inline - #SYP-04 (Figure 6)
Corner - #SYP-20




Figure 1



Figure 2



Figure 3



Figure 4



Yellow Products

630-293-8013

Toll Free 877-"SAVE"TY-1

Fax 630-876-1993

9. Using a level, adjust the top-rail and fittings to be level. Once level, tighten the set screws on the top fittings.
10. Repeat steps 3 – 9 as necessary until the hand-rail run is complete.
11. Save these instructions for future use.



Figure 5



Figure 6