

630-293-8013 Toll Free 877-"SAVE"TY-1 Fax 630-876-1993

## **Drop Down Dock Gate Installation Instructions**

## Included

• Left and Right Mounting Posts • Left and Right Gate Arms • 4 washers • 4 bolts • 2 Spring assisted locking mechanisms

Quick release locking

mechanism.

- 1. Before anchoring, align all pieces to ensure both gate arms Will be aligned when in the closed position.
- 2. Anchor the posts into the desired location, ensuring that the posts are level and in line with each other. (Figure 1).
- 3. Ensure stop sign and black lock knob are facing away from dock door. Insert the locking mechanism to keep the gate arms upright. (Figures 2 3).
- 4. Release the left gate arm lock, and lay it down on the ground first, as this is the "receiving" side. (Figure 4).
- 5. Release the right gate arm lock, and lay it down Inside the left gate arm. (Figures 5 6).
- 6. To return the gate back to the upright Position, lift up the right gate arm and lock it into Place, then lift the left gate arm and lock it into place. (Figure 3)



Figure 1



Figure 2



Figure 3



Figure 4




Figure 5



Figure 6